

LGA20: Commissioning and Closed-Loop operation



Document version:
Nanotec Electronic GmbH & Co. KG
Kapellenstraße 6
85622 Feldkirchen, Germany

1.0.0
Phone: +49 (89) 900 686-0
Fax: +49 (89) 900 686-50
info@nanotec.de

This document provides instructions for commissioning linear actuators with integrated linear guides and attached encoders, specifically in conjunction with the **Closed-Loop controllers** of Nanotec.

You can find the data sheet and mechanical drawings for your actuator and encoder, as well as the manuals for the Nanotec controllers at us.nanotec.com.

Warranty and disclaimer

Nanotec is not liable for damage and malfunction from installation errors, failure to observe this document, or improper repair. Responsible for the selection, operation, use of our products is the plant engineer, operator and user. Nanotec accepts no liability for product integration in the end system. The general terms and conditions at www.nanotec.com apply (customers of Nanotec Electronic USA please see us.nanotec.com). **Note:** Product modification / alteration is illicit.

Auto setup

To determine a number of parameters related to the motor and the attached encoder and relish the advantages of the closed-loop operation, you must perform an auto setup, when using a Nanotec controller.



TIPP

As long as the motor connected to the controller or the encoder are not changed, auto setup is only to be performed once during initial commissioning.



HINWEIS

Note the following prerequisites for performing the auto setup:

- ▶ The motor must be load-free and must not be touched during the setup.
- ▶ At the start of the auto-setup, the motor must be positioned just before the negative limit (→ retract the spindle).
- ▶ Before performing the auto-setup, set the object 203C_h:04_h to "0".

For more information on closed-loop control and auto setup, please refer to the technical manual for your Nanotec controller. The software *Plug&Drive Studio 3* provides a dedicated control element for performing the auto setup and allows you to configure motor current and other parameters.

Homing on block

With this homing method, the motor is referenced to a block (end stop) rather than a limit switch. On Nanotec controllers, this method works only in *Closed Loop* mode.

For more information on closed-loop control and homing, please refer to the technical manual for your Nanotec controller.

HINWEIS



To avoid damage during homing on block:

- ▶ Use a low speed for the homing run. For Nanotec controllers, configure this in the object 6099_h.
- ▶ Set the motor current and the corresponding current threshold for block detection (currently in objects 6075_h und 3219_h) to a low value. Refer to the table below for the maximum permissible value based on the exact part number.

Thread [mm]	LGA201S02	LGA201S03	LGA201S06	LGA201M04	LGA201M07	LGA201M13
UEAI: 3.5x0.3	0.20 A	0.30 A	0.60 A	0.40 A	0.70 A	1.3 A
UEAP: 3.5x0.61	0.20 A	0.30 A	0.60 A	0.40 A	0.70 A	1.3 A
TDBA: 3.5x1	0.20 A	0.30 A	0.60 A	0.40 A	0.70 A	1.3 A
UEBF: 3.5x1.22	0.20 A	0.30 A	0.60 A	0.40 A	0.70 A	1.3 A
UECB: 3.5x2	0.20 A	0.30 A	0.60 A	0.40 A	0.70 A	1.3 A
UEEB: 3.5x4	0.20 A	0.30 A	0.60 A	0.40 A	0.70 A	1.3 A
UEIA: 3.5x8	0.20 A	0.30 A	0.60 A	0.40 A	0.70 A	1.3 A