



Application Note

Starting up a Nanotec Controller/Drive with
Trio MC 4N-ECAT

Version 1.0.0

Contents

1	Prerequisites	1
2	Hardware.....	1
3	Software.....	1
4	Setup Communication	2
4.1	Connect to MC4N	2
4.2	Setting the IP address of the network card	3
5	Loading a project and configuring the communication	4
5.1	Loading the example project	4
5.2	Setup EC_EXTEND.....	6
5.3	Synchronize master and slave	8
6	Description of the example project	10
6.1	HOMING	10
6.2	EXAMPLE_POSITION	11
6.3	Checking the status of the slave	12
7	Liability	13
8	Copyrights and contact	13

1 Prerequisites

The slave drive (Nanotec Controller) must be configured beforehand. Proper operation of the motor and the slave drive must be ensured before the example can be used. Make sure that the controller/drive operation is not hindered, e.g. by a stand-alone program running on the slave.

2 Hardware

- Trio MC4N-ECAT Mini Master
- Nanotec N5-1-1 controller/drive for brushless DC motors and stepper motors


3 Software

Motion Perfect, Version 4.3.3

4 Setup Communication

4.1 Connect to MC4N

1. Install Motion Perfect.
2. Connect the network card of your PC to the MC4N's Programming port via an Ethernet cable.
3. Use a second Ethernet cable to connect MC4N's EtherCAT port to the *EtherCAT IN* RJ45 port of N5-1-1.




EtherCAT Connection Guide with Trio MC4N

4. Apply power to both N5-1-1 and MC4N.
5. Set the IP address of the network card of your PC as described in the next chapter and run the Motion Perfect software.

4.2 Setting the IP address of the network card


The IP address of a MC4N controller is per default 192.168.0.250 and the subnet mask is 255.255.255.0. You need to assign an IP address to the network card of your PC, that is in the same subnet as the MC4N controller. For example, set the network card's IP address to 192.168.0.249, as shown below.




5 Loading a project and configuring the communication

5.1 Loading the example project


1. Download the example project from the Nanotec website www.nanotec.com.
2. Select in the **Connection** window the interface **Ethernet** and click on **Apply & Connect** to connect to MC4N in Sync mode.




3. Click on **Load** to load the example project folder named “Application note”.



The folder contains three files, the configuration file *EC_EXTEND* and the example programs *EXAMPLE_POSITION* and *HOMING*.



The picture below shows that the controller is now connected and the project named “Application note” has been correctly loaded.



5.2 Setup EC_EXTEND


The *EC_EXTEND* file is a text file in XML-format containing configuration data for one or more EtherCAT slave devices. The file can be loaded onto the MC4N so that MC4N is able to interact with the EtherCAT devices whose configuration data is contained in the file. The contents of the file is used to extend the MC4N's built-in dictionary of EtherCAT devices.

Each Nanotec Controller has its own *identity object* (register 1018_h:00_h in the object dictionary) which contains the following:

- vendor ID
- product code
- revision number

To read this object, use the software [Plug&Drive Studio](#) to connect to the Nanotec Controller.

In the tab **Object dictionary** search for the mentioned *identity object* and copy the values of the three entries, which you need to enter manually in *EC_EXTEND* later.



The three entries correspond to the *EC_EXTEND* parameters *Vid*, *Pid* and *Rev* respectively.


Nanotec Controller	EC_EXTEND
• Vendor ID	• Vid
• Product code	• Pid
• Revision number	• Rev

5.3 Synchronize master and slave


1. Open the **Intelligent drives** configuration window.



2. Click **re-initialize the drives** to synchronize the master and slave controllers.
3. If Motion Perfect shows a "System error", you need to reset the MC4N to enable the connection to the Nanotec Controller. To do so, simply click on **Reset MC**.



After the reset of the controller the **Intelligent drives** window shows that the master is synchronized to the slave Nanotec Controller, the Master state is **Operational**.




6 Description of the example project

6.1 HOMING

This example demonstrates the use of the homing mode.

You can use any of the homing methods described in the technical manual of the N5-1-1.

To select the homing method, enter the desired method number as a parameter of **CO_WRITE_AXIS** in the example code, click the save button and compile by clicking the question mark symbol.



Without connecting additional external home switches, you can use the following methods:

CO_WRITE_AXIS(ax,\$6098,\$00,2,-1,33) : homing method 33, references to the next index pulse on the left.


CO_WRITE_AXIS(ax,\$6098,\$00,2,-1,34) : homing method 34, references to the next index pulse on the right.


The prerequisite for these two methods is that the connected motor is equipped with an encoder with an index pulse.


CO_WRITE_AXIS(ax,\$6098,\$00,2,-1,35) : homing method 35, references to the current position

6.2 EXAMPLE_POSITION

The program **EXAMPLE_POSITION** demonstrates the use of the position mode; the motor moves between two relative target positions.

To start the program, click on the **Start** symbol . The motor runs at the set speed (parameter **SPEED**, in motor revolutions per second) between the 2 target positions (argument of function **MOVE**, in motor revolutions) until you stop the program.


To stop the program, click the **Halt** icon .



6.3 Checking the status of the slave

The tab **Status** shows the current status of the connected slave drive, giving data about the drive and motor including the drive status flags and stored alarms. A button is provided to reset the drive.

Double-clicking on a drive icon, a motor icon associated with a drive, or a line in the **Drives** grid will bring up the **EtherCAT device** window for the corresponding drive.



7 Liability

This Application Note is based on our experience with typical user requirements in a wide range of industrial applications. The information in this Application Note is provided without guarantee regarding correctness and completeness and is subject to change by Nanotec without notice.

It serves as general guidance and should not be construed as a commitment of Nanotec to guarantee its applicability to all customer applications without additional tests under the specific conditions and – when necessary – modifications by the customer.

The provided information does not replace datasheets and other product documents. For the latest version of our datasheets and documentations please visit our website at www.nanotec.com.

The responsibility for the applicability and use of the Application Note in a particular customer application lies solely within the authority of the customer. It is the customer's responsibility to evaluate, investigate and decide, whether the Application Note is valid and suitable for the respective customer application, or not.

Defects resulting from the improper handling of devices and modules are excluded from the warranty. Under no circumstances will Nanotec be liable for any direct, indirect, incidental or consequential damages arising in connection with the information provided.

In addition, the regulations regarding the liability from our Terms and Conditions of Sale and Delivery shall apply.

8 Copyrights and contact

Nanotec Electronic GmbH & Co. KG
Kapellenstraße 6
85622 Feldkirchen
Germany

Tel. +49 (0)89 900 686-0
Fax +49 (0)89 900 686-50
info@nanotec.de

www.nanotec.com

© 2019 Nanotec Electronic GmbH & Co. KG, all rights reserved. Motion Perfect V4 is a trademark or registered trademark of Trio Motion Technology Ltd. in United Kingdom and other countries for Trio Motion Technology factory automation products. 11.2019 Germany